

	Product	Code	Box Depth	GBP		Product	Code	Box Depth	GBP		
Rocker Light Switches											
	1 Gang Rocker Switch (10 Amp)	EX9.500.DBZ	35	37.91		2 Gang Rocker Switch (10 Amp)	EX9.510.DBZ	35	49.64		
	3 Gang Rocker Switch (10 Amp) Double Plate	EX9.520.DBZ	35	62.80			4 Gang Rocker Switch (10 Amp)	EX9.530.DBZ	35	75.44	
	1 Gang Intermediate Rocker Switch (10 Amp)	EX9.501.DBZ	35	44.23							
Toggle Light Switches											
	1 Gang Toggle Switch	EX9.2400.DBZ	35	56.22		2 Gang Toggle Switch	EX9.2410.DBZ	35	77.34		
	3 Gang Toggle Switch	EX9.2420.DBZ	35	115.72			4 Gang Toggle Switch	EX9.2430.DBZ	35	120.45	
	1 Gang Intermediate Toggle Switch	EX9.2401.DBZ	35	62.54							
TED Dimmer Switches (Compatible with LED bulbs)											
	1 Gang TED Dimmer (Compatible with LED Lamps)	EX9.560.TED	35	81.26		2 Gang TED Dimmer (Compatible with LED Lamps)	EX9.570.TED	35	112.74		
	3 Gang TED Dimmer (Compatible with LED Lamps)	EX9.580.TED	35	172.58			4 Gang TED Dimmer (Compatible with LED Lamps)	EX9.590.TED	35	196.19	
Plug Sockets											
	Single Socket (13 Amp)	EX9.240.DBZ	35	44.19		Double Socket (13 Amp)	EX9.250.DBZ	35	63.16		
Cooker Switches											
	45A DP Cooker Switch with Neon (single plate)	EX9.263.DBZ	48	60.90		45A Cooker Unit + 13A Socket	EX9.262.DBZ	48	79.52		
Dimmer Switches (Compatible with halogen/ incandescent bulbs)											
	1 Gang Dimmer 250 watts (Compatible with halogen/ incandescent bulbs)	EX9.560.250	35	55.98		1 Gang Dimmer 400 watts (Compatible with halogen/ incandescent bulbs)	EX9.560.400	35	57.48		
	2 Gang Dimmer 250 watts (Compatible with halogen/ incandescent bulbs)	EX9.570.250	35	74.81			2 Gang Dimmer 400 watts (Compatible with halogen/ incandescent bulbs)	EX9.570.400	35	77.34	
	3 Gang Dimmer 250 watts (Compatible with halogen/ incandescent bulbs)	EX9.580.250	35	115.70				3 Gang Dimmer 400 watts (Compatible with halogen/ incandescent bulbs)	EX9.580.400	35	119.51
	4 Gang Dimmer 250 watts (Compatible with halogen/ incandescent bulbs)	EX9.590.250	35	120.35					4 Gang Dimmer 400 watts (Compatible with halogen/ incandescent bulbs)	EX9.590.400	35
USB Sockets											
	Double USB Socket (13 Amp)	EX9.255.DBZ-USB	35	77.94		2G 13A Socket with USB-A+C	C-EX9.2559.DBZ	35	88.16		
Unswitched Socket											
	5 Amp 3 Round Pin Socket	EX9.282.BK	35	50.05							
Shaver Sockets											
	Shaver Socket Output Voltage 110/240V	EX9.285.BK	57	118.83							
Fused Spur Units											
	Unswitched Spur (13 Amp)	EX9.650.BK	35	37.91		Switched Spur (13 Amp)	EX9.235.DBZ	35	50.56		
	Switched Spur with Neon (13 Amp)	EX9.236.DBZ	35	60.63			Switched Spur with Neon + Cord (13 Amp)	EX9.238.DBZ	35	63.16	
Double Pole Switches											

	20A Double Pole Switch	EX9.505.DBZ	35	40.80		20A Double Pole Switch with Neon	EX9.506.DBZ	35	43.33
Fan Isolator Switches									
	6A Triple Pole Fan Isolator Switch	EX9.2990.DBZ	35	50.31					
TV and Satellite Sockets									
	1 Gang Non-Isolated TV Coaxial Socket	EX9.610.BK	35	37.88		1 Gang Isolated TV Coaxial Socket	EX9.610.BK-I	35	40.17
	2 Gang TV Coaxial Socket	EX9.681.BK	35	46.16		TV/FM Diplexed Socket	EX9.680.BK-DIP	35	50.20
	1 Gang Satellite Socket	EX9.605.BK	35	37.88		TV/Satellite Socket	EX9.615.BK	35	46.16
Telephone and Data Sockets									
	1 Gang Secondary Line Socket	EX9.691.BK-S	35	38.22		1 Gang Master Line Socket	EX9.691.BK-M	35	40.77
	2 Gang Secondary Line Socket	EX9.692.BK-S	35	52.59		2 Gang Master Line Socket	EX9.692.BK-M	35	53.85
	1 Gang RJ45	EX09.691.BK-RJ45	35	39.85		1 Gang RJ11	EX9.691.BK-RJ11	35	39.85
	2 Gang RJ45	EX09.692.BK-RJ45	35	52.59		1 Gang CAT6	EX09.691.BK-CAT6	35	43.65
	2 Gang CAT6	EX09.692.BK-CAT6	35	56.89					
Euro Module Plates									
	1 Module Euro Plate	PL. EX9.2691.G		30.27		2 Module Euro Plate	PL. EX9.2692.G		30.27
	4 Module Euro Plate	PL. EX9.2694.G		38.86					
Blank Plates									
	Single Blank Plate	EX9.630		25.21		Double Blank Plate	EX9.640		30.02