

BAUHAUS RANGE - POLISHED BRASS

Prices valid from April 2024. All prices exclusive of VAT.



	Product	Code	Box Depth	GBP		Product	Code	Box Depth	GBP
Rocker Light Switches									
	1 Gang Rocker Switch (10 Amp)	BH1.100.PBW	25	18.84		1 Gang Rocker Switch (10 Amp)	BH1.100.PBBK	25	18.84
	2 Gang Rocker Switch (10 Amp)	BH1.110.PBW	25	23.67		2 Gang Rocker Switch (10 Amp)	BH1.110.PBBK	25	23.67
	3 Gang Rocker Switch (10 Amp)	BH1.120.PBW	25	30.83		3 Gang Rocker Switch (10 Amp)	BH1.120.PBBK	25	30.83
	4 Gang Rocker Switch (10 Amp)	BH1.130.PBW	25	42.24		4 Gang Rocker Switch (10 Amp)	BH1.130.PBBK	25	42.24
	1 Gang Intermediate Rocker Switch (10 Amp)	BH1.101.PBW	25	25.17		1 Gang Intermediate Rocker Switch (10 Amp)	BH1.101.PBBK	25	25.17
Toggle Light Switches									
	1 Gang Toggle Switch	BH1.1400.PB	35	46.47		2 Gang Toggle Switch	BH1.1410.PB	35	62.40
	3 Gang Toggle Switch	BH1.1420.PB	35	90.53		4 Gang Toggle Switch	BH1.1430.PB	35	108.98
	1 Gang Intermediate Toggle Switch	BH1.1401.PB	35	52.78					
TED Dimmer Switches (Compatible with LED bulbs)									
	1 Gang TED Dimmer (Compatible with LED Lamps)	BH1.971.TED	35	69.25		2 Gang TED Dimmer (Compatible with LED Lamps)	BH1.972.TED	35	104.86
	3 Gang TED Dimmer (Compatible with LED Lamps)	BH1.973.TED	35	153.76		4 Gang TED Dimmer (Compatible with LED Lamps)	BH1.974.TED	35	187.11
Plug Sockets									
	Single Socket (13 Amp)	BH1.140.PBW	35	23.55		Single Socket (13 Amp)	BH1.140.PBBK	35	23.55
	Double Socket (13 Amp)	BH1.150.PBW	35	32.78		Double Socket (13 Amp)	BH1.150.PBBK	35	32.78
Cooker Switches									
	45A DP Cooker Switch with Neon (single plate)	BH1.163.W	48	46.91		45A DP Cooker Switch with Neon (single plate)	BH1.163.BK	48	46.91
	45A DP Cooker Switch with Neon (tall plate)	BH1.161.W	48	52.24		45A DP Cooker Switch with Neon (tall plate)	BH1.161.BK	48	52.24
	45A Cooker Unit + 13A Socket	BH1.162.W	48	70.98		45A Cooker Unit + 13A Socket	BH1.162.BK	48	70.98
Dimmer Switches (Compatible with halogen/ incandescent bulbs)									
	1 Gang Dimmer 250 watts (Compatible with halogen/ incandescent bulbs)	BH1.971.250	35	42.45		1 Gang Dimmer 400 watts (Compatible with halogen/ incandescent bulbs)	BH1.971.400	35	42.93
	2 Gang Dimmer 250 watts (Compatible with halogen/ incandescent bulbs)	BH1.972.250	35	64.66		2 Gang Dimmer 400 watts (Compatible with halogen/ incandescent bulbs)	BH1.972.400	35	72.38
	3 Gang Dimmer 250 watts (Compatible with halogen/ incandescent bulbs)	BH1.973.250	35	92.80		3 Gang Dimmer 400 watts (Compatible with halogen/ incandescent bulbs)	BH1.973.400	35	103.70
	4 Gang Dimmer 250 watts (Compatible with halogen/ incandescent bulbs)	BH1.974.250	35	111.27		4 Gang Dimmer 400 watts (Compatible with halogen/ incandescent bulbs)	BH1.974.400	35	125.56
USB Sockets									
	Double USB Socket (13 Amp)	BH1.755.PBW-USB	35	59.29		Double USB Socket (13 Amp)	BH1.755.PBB-USB	35	59.29
	2G 13A Socket with USB-A+C	C-BH1.7559.PBW	35	62.78		2G 13A Socket with USB-A+C	C-BH1.7559.PBBK	35	62.78

Unswitched Socket										
	5 Amp 3 Round Pin Socket	BH1.182.W	35	32.51			5 Amp 3 Round Pin Socket	BH1.182.BK	35	32.51
Shaver Sockets										
	Shaver Socket Output Voltage 110/240V	BH1.985.W	48	70.98			Shaver Socket Output Voltage 110/240V	BH1.985.BK	48	70.98
Fused Spur Units										
	Unswitched Spur (13 Amp)	BH1.134.W	35	26.45			Unswitched Spur (13 Amp)	BH1.134.BK	35	26.45
	Switched Spur (13 Amp)	BH1.135.PBW	35	30.74			Switched Spur (13 Amp)	BH1.135.PBBK	35	30.74
	Switched Spur with Neon (13 Amp)	BH1.136.PBW	35	36.86			Switched Spur with Neon (13 Amp)	BH1.136.PBBK	35	36.86
	Switched Spur with Neon + Cord (13 Amp)	BH1.138.PBW	35	46.27			Switched Spur with Neon + Cord (13 Amp)	BH1.138.PBBK	35	46.27
Double Pole Switches										
	20A Double Pole Switch	BH1.105.PBW	35	27.53			20A Double Pole Switch	BH1.105.PBBK	35	27.53
	20A Double Pole Switch with Neon	BH1.106.PBW	35	31.62			20A Double Pole Switch with Neon	BH1.106.PBBK	35	31.62
Fan Isolator Switches										
	6A Triple Pole Fan Isolator Switch	BH1.1990.W	25	30.88			6A Triple Pole Fan Isolator Switch	BH1.1990.BK	25	30.88
TV and Satellite Sockets										
	1 Gang Non-Isolated TV Coaxial Socket	BH1.921.W	35	24.32			1 Gang Non-Isolated TV Coaxial Socket	BH1.921.BK	35	24.32
	1 Gang Isolated TV Coaxial Socket	BH1.923.W	35	28.10			1 Gang Isolated TV Coaxial Socket	BH1.923.BK	35	28.10
	2 Gang TV Coaxial Socket	BH1.922.W	35	28.54			2 Gang TV Coaxial Socket	BH1.922.BK	35	28.54
	TV/FM Diplexed Socket	BH1.924.W-DIP	35	39.95			TV/FM Diplexed Socket	BH1.924.BK-DIP	35	39.95
	1 Gang Satellite Socket	BH1.925.W	35	28.10			1 Gang Satellite Socket	BH1.925.BK	35	28.10
	TV/Satellite Socket	BH1.926.W	35	31.68			TV/Satellite Socket	BH1.926.BK	35	31.68
Telephone and Data Sockets										
	1 Gang Secondary Line Socket	BH1.966.W-S	35	27.95			1 Gang Secondary Line Socket	BH1.966.BK-S	35	27.95
	1 Gang Master Line Socket	BH1.967.W-M	35	31.29			1 Gang Master Line Socket	BH1.967.BK-M	35	31.29
	2 Gang Secondary Line Socket	BH1.956.W-S	35	46.53			2 Gang Secondary Line Socket	BH1.956.BK-S	35	46.53
	2 Gang Master Line Socket	BH1.957.W-M	35	47.79			2 Gang Master Line Socket	BH1.957.BK-M	35	47.79
	1 Gang RJ45	BH1.968.W-RJ45	35	33.12			1 Gang RJ45	BH1.968.BK-RJ45	35	33.12
	1 Gang RJ11	BH1.969.W-RJ11	35	33.12			1 Gang RJ11	BH1.969.BK-RJ11	35	33.12
	2 Gang RJ45	BH1.958.W-RJ45	35	46.53			2 Gang RJ45	BH1.958.BK-RJ45	35	46.53
	1 Gang CAT6	BH1.968.W-CAT6	35	36.91			1 Gang CAT6	BH1.968.BK-CAT6	35	36.91
	2 Gang CAT6	BH1.958.W-CAT6	35	55.11			2 Gang CAT6	BH1.958.BK-CAT6	35	55.11
Euro Module Plates										
	1 Module Euro Plate	PL.BH1.691.W		21.37			1 Module Euro Plate	PL.BH1.691.BK		21.37
	2 Module Euro Plate	PL.BH1.692.W		21.37			2 Module Euro Plate	PL.BH1.692.BK		21.37
	4 Module Euro Plate	PL.BH1.1694.W		27.70			4 Module Euro Plate	PL.BH1.1694.BK		27.70
Blank Plates										

☐	Single Blank Plate	BH1.931		18.46	☐	Double Blank Plate	BH1.932		22.13
--------------------------	--------------------	---------	--	-------	--------------------------	--------------------	---------	--	-------