

	20A Double Pole Switch	EX23.505.PCBK	35	40.80		20A Double Pole Switch with Neon	EX23.506.PCBK	35	43.33
Fan Isolator Switches									
	6A Triple Pole Fan Isolator Switch	EX23.2990.PCBK	35	50.31					
TV and Satellite Sockets									
	1 Gang Non-Isolated TV Coaxial Socket	EX23.610.BK	35	37.88		1 Gang Isolated TV Coaxial Socket	EX23.610.BK-I	35	40.17
	2 Gang TV Coaxial Socket	EX23.681.BK	35	46.16		TV/FM Diplexed Socket	EX23.680.BK-DIP	35	50.20
	1 Gang Satellite Socket	EX23.605.BK	35	37.88		TV/Satellite Socket	EX23.615.BK	35	46.16
Telephone and Data Sockets									
	2 Gang Secondary Line Socket	EX23.692.BK-S	35	52.59		2 Gang Master Line Socket	EX23.692.BK-M	35	53.85
	1 Gang RJ45	EX23.691.BK-RJ45	35	39.85		1 Gang RJ11	EX23.691.BK-RJ11	35	39.85
	2 Gang RJ45	EX23.692.BK-RJ45	35	52.59		1 Gang CAT6	EX23.691.BK-CAT6	35	43.65
	2 Gang CAT6	EX23.692.BK-CAT6	35	56.89		1 Gang Secondary Line Socket	EX23.691.BK-S	35	38.22
	1 Gang Master Line Socket	EX23.691.BK-M	35	40.77					
Euro Module Plates									
	1 Module Euro Plate	PL.EX23.2691.G		30.27		2 Module Euro Plate	PL.EX23.2692.G		30.27
	4 Module Euro Plate	PL.EX23.2694.G		38.86					
Blank Plates									
	Single Blank Plate	EX23.630		25.21		Double Blank Plate	EX23.640		30.02