

	20A Double Pole Switch with Neon	EX25.506.PCBK	35	43.33		20A Double Pole Switch	EX25.505.PCBK	35	40.80
Fan Isolator Switches									
	6A Triple Pole Fan Isolator Switch	EX25.2990.PCBK	35	50.31					
TV and Satellite Sockets									
	1 Gang Non-Isolated TV Coaxial Socket	EX25.610.BK	35	37.88		1 Gang Isolated TV Coaxial Socket	EX25.610.BK-I	35	40.17
	2 Gang TV Coaxial Socket	EX25.681.BK	35	46.16		TV/FM Diplexed Socket	EX25.680.BK-DIP	35	50.20
	1 Gang Satellite Socket	EX25.605.BK	35	37.88		TV/Satellite Socket	EX25.615.BK	35	46.16
Telephone and Data Sockets									
	1 Gang Secondary Line Socket	EX25.691.BK-S	35	38.22		1 Gang Master Line Socket	EX25.691.BK-M	35	40.77
	2 Gang Secondary Line Socket	EX25.692.BK-S	35	52.59		2 Gang Master Line Socket	EX25.692.BK-M	35	53.85
	1 Gang RJ45	EX25.691.BK-RJ45	35	39.85		1 Gang RJ11	EX25.691.BK-RJ11	35	39.85
	2 Gang RJ45	EX25.692.BK-RJ45	35	52.59		1 Gang CAT6	EX25.691.BK-CAT6	35	43.65
	2 Gang CAT6	EX25.692.BK-CAT6	35	56.89					
Euro Module Plates									
	1 Module Euro Plate	PL.EX25.2691.G		30.27		2 Module Euro Plate	PL.EX25.2692.G		30.27
	4 Module Euro Plate	PL.EX25.2694.G		38.86					
Blank Plates									
	Single Blank Plate	EX25.630		25.21		Double Blank Plate	EX25.640		30.02